



## ESSENTIAL INGREDIENTS

POLE + BRACKETS  
WEIGHTS

## PREPARATION

CUT OUT 2 CURTAINS - TABS - 2 PIECES FOR FRILLS

DECIDE ON DEPTH OF FRILL - 1/3 OF YOUR CURTAIN LENGTH IS ABOUT RIGHT FOR THIS DESIGN. CUT THE FRILL FABRIC 1 1/2 TIMES WIDTH OF EACH CURTAIN. ALLOW 2CMS (1") FOR GATHERING SEAM AND 10CMS (4") FOR HEM



WORK OUT NUMBER OF TABS REQUIRED, THEY SHOULD BE APPROXIMATELY EVERY 15CMS (6") APART. TABS NEED TO BE 5CMS (2") WIDE, THE LENGTH ABOUT 10CMS (4") DOUBLED BUT IT DOES DEPEND ON THE THICKNESS OF THE POLE.



## TIP

THROW A CLOTH TAPE MEASURE OVER THE POLE ONE END TOUCHING THE FLOOR + THE OTHER END OVER THE POLE AND THEN YOU CAN WORK OUT ALL THE MEASUREMENTS BUT DON'T FORGET TO ADD HEM ALLOWANCES.



## GETTING STARTED

1. GATHER YOUR FRILL PIECE WITH A RUNNING STITCH ABOUT 1CM (1/2") FROM EDGE PULL GATHERING UNTIL IT IS THE SAME WIDTH AS THE BASE CURTAIN. SECURE STITCHING, PIN AS USUAL.
2. PRESS SEAM TOWARD CURTAIN AND TOP STITCH NEAR SEAM.
3. SLIP STITCH YOUR SIDE SEAMS AND HEM AND PRESS
4. TABS - MACHINE TABS - 1CM (1/2") AND TURN THROUGH AND PRESS
5. ON RIGHT SIDE OF FABRIC AT TOP OF CURTAINS ATTACH TAB AS IN DIAGRAM
6. TURN OVER SEAM AND TABS AND PRESS FIRMLY - LASTLY CUT A STRIP OF FABRIC AND STITCH OVER.

